Bedienungsanleitung

Seite: 1-4

User Manual

Page: 5 - 8

Platinum Line CLS-3 QUAD

28x 8 Watt Quad LED (RGBW)

LIG0009245-000

Lieber Kunde,

vielen Dank das Sie sich für ein Produkt von LightmaXX entschieden haben. In der folgenden Anleitung erhalten Sie wichtige Informationen über dieses Produkt sowie deren Eigenschaften und Funktionen.

Technische Daten:

Spannungsversorgung	240 V / 50 Hz
Leistungsaufnahme	Max. 250 Watt
LED System	28x 8W Quad (RGBW)
Funktionsweise	4, 6, 7, 16 Kanal
Maße	1030 x 100 x 290 mm
Gewicht	7,0 Kg

Fernbedienung:

BL: AN / AUS

SP: Geschwindigkeit
1x drücken= langsam
2x drücken= mittel
3x drücken= schnell
4x drücken= STOP

☼ Helligkeit
1x drücken= 50%
2x drücken= 75%
3x drücken= 100% (FULL ON)
4x drücken= AUS

FL: Strobe
1x drücken= langsam
2x drücken= mittel
3x drücken= schnell
4x drücken= STOP

R/G/B/W: Farbanwahl der Einzelfarben

Pr1 – Pr4: Farbwechselprogramme, Über **SP** lässt sich die Geschwindigkeit regeln.
D1 – D4: Farbübergänge, Über **SP** lässt sich die Geschwindigkeit regeln.
SA1 – SA4: Sound Aktive Programme.
ON1/OFF1: Schaltbare Steckdose 1 am Gehäuse.
ON2/OFF2: Schaltbare Steckdose 2 am Gehäuse.

DMX Protokoll:

6 Kanal Modus:

Kanal	DMX Wert	Funktion
1	000-255	Rot (0-100%)
2	000-255	Grün (0-100%)
3	000-255	Blau (0-100%)
4	000-255	Weiss (0-100%)
5	000-255	Master Dimmer (0-100%)
6	000-000	AN
	001-005	Sound control (15 Farben)
	006-010	AN
	011-255	Strobe

4 Kanal Modus:

Kanal	DMX Wert	Funktion
1	000-255	Rot (0-100%)
2	000-255	Grün (0-100%)
3	000-255	Blau (0-100%)
4	000-255	Weiss (0-100%)

7 Kanal Modus:

<table>
<tr><td>CH1</td><td>CH2</td><td>CH3</td><td>CH4</td><td>CH5</td><td>CH6</td><td>CH7</td></tr>
<tr><td>0-15</td><td rowspan="16">Master dimmer</td><td rowspan="25">Flash
0-255
Slow to fast</td><td>R
0-255)</td><td>G
(0-255)</td><td>B
(0-255)</td><td>W
(0-255)</td></tr>
<tr><td>16-23 R</td><td rowspan="23"></td><td rowspan="23"></td><td rowspan="23" colspan="2"></td></tr>
<tr><td>24-31 G</td></tr>
<tr><td>32-39 B</td></tr>
<tr><td>40-47 W</td></tr>
<tr><td>48-55 RG</td></tr>
<tr><td>56-63 GB</td></tr>
<tr><td>64-71 BW</td></tr>
<tr><td>72-79 WR</td></tr>
<tr><td>80-87 GW</td></tr>
<tr><td>88-95 RB</td></tr>
<tr><td>96-103 RGB</td></tr>
<tr><td>104-111 GBW</td></tr>
<tr><td>112-119 RGW</td></tr>
<tr><td>120-127 RBW</td></tr>
<tr><td>128-135 RGBW</td></tr>
<tr><td>136-143 Dream</td><td rowspan="14">Speed control
(0-255)
Slow to fast</td></tr>
<tr><td>144-151 Meteor</td></tr>
<tr><td>152-159 Fade</td></tr>
<tr><td>160-167 Change</td></tr>
<tr><td>168-175 Flow1</td></tr>
<tr><td>176-183 Flow2</td></tr>
<tr><td>184-191 Flow3</td></tr>
<tr><td>192-199 Flow4</td></tr>
<tr><td>200-207 Flow5</td></tr>
<tr><td>208-215 Flow6</td></tr>
<tr><td>216-223 Flow7</td></tr>
<tr><td>224-231 Flow8</td><td>15 color section</td><td>15color section</td><td colspan="2"></td></tr>
<tr><td>232-239 Flow9</td><td>15 color section</td><td>15color section</td><td colspan="2"></td></tr>
<tr><td>240-255 Sound</td><td>Sensitivity
(0-255)</td><td></td><td colspan="4"></td></tr>
</table>

16 Kanal Modus:

CH 1	CH 2	CH 3	CH 4	CH 5	CH 6	CH 7	CH 8	CH 9	CH 10	CH 11	CH 12	CH 13	CH 14	CH 15	CH 16
R1	G1	B1	W1	R2	G2	B2	W2	R3	G3	B3	W3	R4	G4	B4	W4

Welcome to use the powerful series of innovative QUAD LED T-BAR system. It is with LCD digital display for the most convenient operation by using with the foot controller. With the smart design for the fastest installation within 2 minutes for the end users.

Technical Specifications:

Power supply:	**AC240V. 60Hz**
Power consumption:	**Max. 250W**
LED quantity:	**28x 8W Quad (4in1, RGBW)**
DMX control:	**4CH, 6CH, 7CH, 16CH**
DMX connection:	**3-pin**
Foot controller connetion:	**5-pin**
Power:	**IEC IN & OUT**
Beam angle:	**25 degree**
Fuse:	**F2A**
Dimension (L x W x H)	**1030x 100 x 290mm**
Weight:	**7.0kgs**

Operation instructions:

- ***Built-in programs (P01-P14)***

STATIC COLOR BLAC-RGB Flash00-99	Blackout, Red-Yellow-Green-Cyan-Blue-Purple-White Flash speed adjustable.
DREAM Speed00-99 Flash00-99	Seven color dreaming Speed & Flash adjustable
METEOR Speed00-99 Flash00-99	Seven color flow Speed & Flash adjustable
FADE Speed00-99 Flash00-99	Seven color fade Speed & Flash adjustable
CHANGE Speed00-99 Flash00-99	Seven color change Speed & Flash adjustable
FLOW 1 Speed00-99 Flash00-99	Seven color chase in 1 way Speed & Flash adjustable
FLOW 2 Speed00-99 Flash00-99	Seven color chase in 2 ways Speed & Flash adjustable
FLOW 3 Speed00-99 Flash00-99	Seven color chase in 1 relay way Speed & Flash adjustable
FLOW 4 Speed00-99 Flash00-99	Seven color chase in 2 relay ways Speed & Flash adjustable
FLOW 5 Speed00-99 Flash00-99	Seven color chase from two sides to middle Speed & Flash adjustable
FLOW 6 Speed00-99 Flash00-99	Seven color chase from middle to two sides Speed & Flash adjustable
FLOW 7 Speed00-99 Flash00-99	Seven color chase Speed & Flash adjustable
FLOW 8 Speed00-99 Flash00-99 C1. –RGBW C2. -RGBW	Two color chase in 1 way Speed & Flash adjustable
FLOW 9 Speed00-99 Flash00-99 C1. –RGBW C2. -RGBW	Two color chase in 2 ways Speed & Flash adjustable

- ***Auto Run mode (13 built-in modes together)***
  FQN01-99 (Frequency adjustable)

- ***SLAVE Mode:***

Link the units and press MODE button of the Slave units to SLAVE mode. Then the slave units will follow running in accordance with the Master unit.

- ***Sound Active Mode*:**

Press MODE button into SOUND controlling mode, then the fixture will run via the sound.
Press UP & DOWN to adjust the sound sensitivity levels (SENS00-31) & frequency (FQN01-99).

- ***DMX Mode***

  Channel mode: (4CH, 6CH, 7CH, 16CH, 19CH optional)
  4CH: Every four spot eyes as 1 section
  6CH: Every four spot eyes as 1 section
  7CH: Every four spot eyes as 1 section, totally 2 sections
  16CH: Every one spot eye as 1 section, totally 4 sections

6 channel mode:

Channel:	**Value:**	**Function:**
1	000-255	Red (0-100%)
2	000-255	Green (0-100%)
3	000-255	Blue (0-100%)
4	000-255	Amber (0-100%)
5	000-255	Master dimmer (0-100%)
6	000-000	ON
	001-005	Sound control (15 colors)
	006-010	ON
	011-255	Strobe (increasing)

4 channel mode:

Channel:	Value:	Function:
1	000-255	Red (0-100%)
2	000-255	Green (0-100%)
3	000-255	Blue (0-100%)
4	0000-255	Amber (0-100%)

7 channel mode:

<table>
<tr><th>CH1</th><th>CH2</th><th>CH3</th><th>CH4</th><th>CH5</th><th>CH6</th><th>CH7</th></tr>
<tr><td>0-15</td><td rowspan="14">Master dimmer</td><td rowspan="25">Flash 0-255 Slow to fast</td><td>R 0-255)</td><td>G (0-255)</td><td>B (0-255)</td><td>W (0-255)</td></tr>
<tr><td>16-23 R</td><td rowspan="24"></td><td rowspan="24"></td><td rowspan="24" colspan="2"></td></tr>
<tr><td>24-31 G</td></tr>
<tr><td>32-39 B</td></tr>
<tr><td>40-47 W</td></tr>
<tr><td>48-55 RG</td></tr>
<tr><td>56-63 GB</td></tr>
<tr><td>64-71 BW</td></tr>
<tr><td>72-79 WR</td></tr>
<tr><td>80-87 GW</td></tr>
<tr><td>88-95 RB</td></tr>
<tr><td>96-103 RGB</td></tr>
<tr><td>104-111 GBW</td></tr>
<tr><td>112-119 RGW</td></tr>
<tr><td>120-127 RBW</td></tr>
<tr><td>128-135 RGBW</td></tr>
<tr><td>136-143 Dream</td><td rowspan="13">Speed control (0-255) Slow to fast</td></tr>
<tr><td>144-151 Meteor</td></tr>
<tr><td>152-159 Fade</td></tr>
<tr><td>160-167 Change</td></tr>
<tr><td>168-175 Flow1</td></tr>
<tr><td>176-183 Flow2</td></tr>
<tr><td>184-191 Flow3</td></tr>
<tr><td>192-199 Flow4</td></tr>
<tr><td>200-207 Flow5</td></tr>
<tr><td>208-215 Flow6</td></tr>
<tr><td>216-223 Flow7</td></tr>
<tr><td>224-231 Flow8</td><td>15 color section</td><td>15color section</td><td colspan="2"></td></tr>
<tr><td>232-239 Flow9</td><td>15 color section</td><td>15color section</td><td colspan="2"></td></tr>
<tr><td>240-255 Sound</td><td>Sensitivity (0-255)</td><td></td><td colspan="4"></td></tr>
</table>

16 channel mode: (Eevery 1 spot eye as 1 section, the fixture has 4 sections totally)

CH 1	CH 2	CH 3	CH 4	CH 5	CH 6	CH 7	CH 8	CH 9	CH 10	CH 11	CH 12	CH 13	CH 14	CH 15	CH 16
R1	G1	B1	W1	R2	G2	B2	W2	R3	G3	B3	W3	R4	G4	B4	W4

IR remote control instructions:

Press the IR switcher on the bar to ON, the idicator become red, then the fixture will be controlled only by the IR remote control.

BL=On/Off
SP=speed, a (press 1st =slow, 2nd =medium, 3rd =fast 4th = off)
☼ =brightness (press 1st =50%, 2nd =75%, 3rd =100%, 4th = off)
FL=flash, (press 1st =slow, 2nd =medium, 3rd =fast, 4th = off)
R/G/B/W= color select
Pr1-Pr4=color change (speed can be adjust via **SP** button, via **FL** to adjust Flash)
D1-D4= dream (speed can be adjust via **SP** button, via **FL** to adjust Flash)
SA1-SA4=sound active in 4 running effect from **SA1-SA4**.
ON1/ON2=adding light1/light2 on top of the bar to ON
OFF1/OFF2=adding light1/light2 on top of the bar to OFF

www.musicstore.de